



NERO
LINK

QUICK START

CONNECTION

1. Download and install the OSD Audio App for your iOS or Android device.
2. USB DC IN: - Power the NERO Link with the included micro USB cord.
3. WPS: - Link your device to the NERO LINK to your WiFi network by following the setup steps in the app.
4. Line Out 3.5mm stereo-RCA: - Connect the NERO to any Hi-Fi system with RCA stereo input.
5. Line In 3.5mm stereo: - Connect to an optional audio source.



WARRANTY

All OSD AUDIO electronics have (2) year Limited Warranty against defects in materials and workmanship. Proof of purchase must accompany all claims. During the warranty period OSD AUDIO will replace any defective part and correct any defect in workmanship without charge for either parts or labor.

OSD AUDIO may replace returned electronics with a product of equal value and performance. In such cases, some modifications to the mounting may be necessary and are not OSD AUDIO's responsibility.

Damage to or destruction of components due to application of excessive power voids the warranty on those parts. In these cases, repairs will be made on the basis of the retail value of the parts and labor. To return for repairs, you must email customer service at RMA@audiogeargroup.com for a Returned Merchandise Authorization (RMA) number then the unit must be shipped to OSD AUDIO at the owner's expense, along with a note explaining the nature of service required. Be sure to pack the product(s) in a corrugated container with at least 3 inches of resilient material to protect the unit from damage in transit.

This Warranty Does Not Cover: Damage caused by abuse, accident, misuse, negligence, or improper operation (installation). Any products that have been altered or modified. Any product whose identifying number of decal, serial #, etc. has been altered, defaced or removed. Normal wear and maintenance.