




On-Wall Installation



Using the supplied hardware install the 2 mounting screws into the desired mounting location.




Line up the mounting screws with the mounting slots on the back of the SL800 and install.




Double check that the SL800 is securely mounted.

Under Sofa or Floor Placement



Install the supplied non slip feet to the back of the cabinet.



Place under sofa or desired location.



Specifications

Woofer:	8" @ 4 ohm
Passive Radiator:	10"
Enclosure:	Tuned Sealed Cabinet
Power Handling:	300W RMS
Freq Response:	30 - 800Hz
Dimensions:	H 28" x W 14.5" x D 4.75"
Weight:	26 lbs

Warranty Information

All OSD AUDIO speaker products have (10) year Limited Warranty against defects in materials and workmanship. Proof of purchase must accompany all warranty claims. During the warranty period OSD AUDIO will replace any defective part and correct any defect in workmanship without charge for either parts or labor. OSD AUDIO may replace returned speakers with a product of equal value and performance. In such cases, some modifications to the mounting may be necessary and are not OSD AUDIO's responsibility.

For this warranty to apply, the unit must be installed and used according to its written instructions. If necessary, repairs must be performed by OSD AUDIO. The unit must be returned to OSD AUDIO at the owner's expense and with prior written permission. Accidental damage and shipping damage are not considered defects, nor is damage resulting from abuse or from servicing performed by an agency or person not specifically authorized in writing by OSD Audio. OSD AUDIO sells products only through authorized dealers and distributors to ensure that customers obtain proper support and service. Any OSD AUDIO product purchased from an unauthorized dealer or other source, including retailers, mail order dealers and online sellers will not be honored or serviced under existing OSD AUDIO warranty policy.

Any sale of product by an unauthorized source or other manner not authorized by OSD AUDIO shall void the warranty on the applicable product. Damage to, or destruction of components due to application of excessive power voids the warranty on those parts. In these cases, repairs will be made on the basis of the retail value of the parts and labor. To return for repairs, you must email customer service at RMA@OSDAUDIO.com for a Returned Merchandise Authorization (RMA) number# then the unit must be shipped to OSD AUDIO at the owner's expense, along with a note explaining the nature of service required. Be sure to pack the speaker(s) in a corrugated container with at least 3 inches of resilient material to protect the unit from damage in transit.

This Warranty Does Not Cover: Damage caused by abuse, accident, misuse, negligence, or improper operation (installation) • Any products that have been altered or modified • Any product whose identifying number of decal, serial #, etc. has been altered, defaced or removed • Normal wear and maintenance.