


SQ6 UNIVERSAL GRILLE

Connection

The SQ6 is designed to work with multiple OSD models to convert a traditional round grille speaker into a square grille to match decor or ceiling fixtures.

- 1. Remove speaker from the ceiling and place the new grille adapter over the speaker.
- 2. Remount the speaker.
- 3.Install new square grille to complete.

(See Diagram 1.)



Fits The Following OSD Speakers:

BK-R62A	BK-R62SM
BK-R63A	ACE640TT
BK-R62SS	ACE670
BK-R51	ACE600ST
BK-R52	OSD-ACE600
BK-R53	OSD-ACE640
BK-R61	OSD-ACE650
BK-R62	OSD-ACE500
BK-R63	OSD-ACE550

WARRANTY

All OSD Audio speaker products have (10) Year Limited Warranty against defects in materials and workmanship. Proof of purchase must accompany all claims. During the warranty period OSD Audio will replace any defective part and correct any defect in workmanship without charge for either parts or labor OSD Audio may replace returned speakers with a product of equal value and performance. In such cases, some modification to the mounting may be necessary and are not OSD Audios responsibility.

For this warranty to apply, the unit must be installed and used according to its written instructions. If necessary, repairs must be performed by OSD Audio. The unit must be returned to OSD Audio at the owner's expense and with prior written permission. Accidental damage and shipping damage are not considered defects, nor is damaged resulting from abuse or from servicing performed by an agency or person not specifically authorized in writing by OSD Audio

OSD Audio sells products only through authorized dealers and distributors to ensure that customers obtain proper support and service. Any OSD Audio product purchased from an unauthorized dealer or other source, including retailers, mail over dealers and on-line sellers will not be honored or serviced under existing OSD Audio warranty policy. Any sale of product by an unauthorized source or other manner not authorized by OSD Audio shall void the warranty on the applicable product.

Damage to or destruction of components due to application of excessive power voids the warranty on those parts. In these cases, repairs will be made on the basis of the retail value of the parts and labor. To return for repairs, you must email customer service at RMA@audiogeargroup.com for a Returned Merchandise Authorization (RMA) number# then the unit must be shipped to OSD Audio at the owner's expense, along with a note explaining the nature of service required. Be sure to pack the speaker(s) in a corrugated container with at least 3 inches of resilient material to protect the unit from damage in transit.

This Warranty Does Not Cover: Damage caused by abuse, accident, misuse, negligence, or improper operation (installation) • Any products that have been altered or modified • Any product whose identifying number of decal, serial #, etc. has been altered, defaced or removed • Normal wear and maintenance.