

The OSD SKR-120 features audiophile sound quality with virtually no high or low end roll off. A non-shorting design which prevents amplifier damage. Color coded right angle solder-less speaker terminals with easy top termination. Faceplate colors include White, Almond, & Ivory with matching knobs. The continuous slide switch offers 36dB of attenuation with Off and full On settings.

## INSTALLATION INSTRUCTIONS

The SKR-120 is simple to install. Pay attention to the following steps:

1. Route the cables into the volume control J-box in a way that allows for easy access to the connectors on the SKR.
2. Make sure to use the integral strain reliefs where appropriate when routing the cable in the J-box.
3. Make the input and output cables accordingly for easy installation.
4. Strip the wire insulation off the ends of each the eight individual wires ( four front the amplifier and four to the speakers ) at about 1/4". Twist exposed ends together.
5. Connect the leads from the amplifier to the volume control connector according to the label input Left ( + - ) and Right ( + - ).
6. Connect the speakers wires to the connector labeled Output Left ( + - ) and Right ( + - ). Speaker wires typically use the following color configuration:  
  
Red/Black = Right Speaker Red = Positive (+) Black = Ground (-)  
  
White/Green = Left Speaker White = Positive (+) Green = Ground (-)
7. Insert the volume control into the J-box. Mount carefully to make sure no wires are pinched or shorting.

## Limited Warranty

OSD Audio will repair or replace any defect it in material or workmanship which occurs during normal use of this product with new or rebuilt parts free of charge in the US for five years from date of original purchase. This warranty does not cover damages in shipment, failure caused by other products not supplied by OSD Audio or failures due to accident, misuse, or alteration of the equipment. This warranty is extended only to the original purchaser and a purchase receipt, invoice or other proof of original date will be required before warranty repairs are provided

Mail in service can be obtained during period by emailing [RMA@audiogeargroup.com](mailto:RMA@audiogeargroup.com). A return authorization number must be obtained in advance and be marked on the outside of the shipping carton.

This warranty gives you specific legal rights and may have other rights (which vary from state to state). If a problem with this product develops during or after the warranty period please contact OSD Audio or your dealer.